



# Dell Inspiron 1525 Heat Sink Replacement

Replace the heat sink in a Dell Inspiron 1525.

Written By: Miroslav Djuric



## INTRODUCTION

Use this guide to help you replace the heat sink in a Dell Inspiron 1525.

---



### TOOLS:

- [Arctic Silver ArctiClean](#) (1)
  - [Arctic Silver Thermal Paste](#) (1)
  - [Phillips #1 Screwdriver](#) (1)
-



## Step 1 — Battery



- Locate the battery release switch on the bottom of the laptop.

## Step 2



- Slide the battery release switch away from the lock symbol until you hear the battery click.
- Slide the battery towards the back of the laptop until it comes free.

## Step 3 — Bottom Cover



- Remove/loosen the eight 4.80 mm Phillips #1 screws securing the bottom panel.
  - The screws may only need to be loosened, as they are generally retained by plastic washers.
- Remove the bottom panel.

## Step 4 — Heat Sink



- Loosen the five #1 Phillips screws securing the heat sink and clean it with compressed air
  - ⓘ These screws are attached to the heat sink assembly.
- Gently lift the heat sink from side indicated in the picture.
  - ⓘ The heat sink may feel like it is glued to the chips because of the thermal paste. Gently wiggle the heat sink back and forth to help break it free.
- ⓘ Be sure to thoroughly clean off the old thermal paste and apply new thermal paste before reinstalling the heat sink. Follow our [thermal paste application guide](#) for detailed instructions.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 03:20:02 AM.